

in.k600



Series of full-function and multi-feature keypads
with menu driven interface

TechBook

Giving full control to wet fingers!



Aeware 
by gecko



Table of contents

overview	3
warning	4
function description	5
icon description	6
installation	
- low & high profile	9
- drilling templates.....	10
connections.....	12
main modes.....	13
functions	14
spa settings.....	20
keypad settings.....	25
clock setting.....	30
viewing info	31
audio mode in.tune/in.pix	
- tuner mode.....	35
- cd mode	36
- sound options.....	38
- dvd mode in.pix	40
specifications.....	42







in.k600

Advanced series of full-function keypads that give complete control to wet fingers!

With its stunning design, Aeware's new in.k600 series of advanced keypads feature high and low profile versions, large LCD displays, menu-driven or streamlined interfaces and raised keys. With menu-driven models, users can control all functions and programming of not only their spa system but also peripheral accessories like our in.pix dvd/cd player and receiver, or our in.tune receiver/cd player creating a true and unique Aeware experience directly from your spa side.



in.k600 high profile



in.k600 low profile

**WARNINGS:**

Before installing or connecting the unit, please read the following.


FAILURE TO COMPLY WITH THE FOLLOWING WARNINGS MAY SIGNIFICANTLY SHORTEN THE PRODUCT'S LIFE TIME, AND LEAD TO FAILURES AS WELL AS HAZARDOUS CONDITIONS*. COMMON SENSE MUST ALWAYS PREVAIL WHEN EVALUATING THE INSTALLATION AND/OR USE OF ANY ELECTRONIC CONTROL IN A FINAL APPLICATION.


- The maximum ambient conditions this PRODUCT is subjected to (temperature, humidity, etc.) are not to be exceeded.
- This PRODUCT must be installed by qualified personnel.
- Only qualified personnel are to service this PRODUCT. There are no user serviceable parts inside.
- This PRODUCT is only compatible with Aeware's in.pac line of products.
- This PRODUCT should be installed on a clean flat surface.


- The gasket on the back of the unit will prevent water infiltration inside, behind the mounted surface. If the gasket is damaged, the user must seal the back of the unit with silicone to avoid any leakage behind the mounted surface.

*** HAZARDOUS CONDITION:**

A condition that is potentially damaging and/or dangerous to its operator or surroundings. This includes, but is not limited to: fire, flooding or other water damage, dielectric breakdowns (presence of high voltage), etc.







Icon Description



Light icon

The "Light" icon becomes animated when the light is on. The icon animation speed is proportional to the light intensity.



Pumps icons

The "Pump" indicator numbers light up and their icons become fast animated when pumps are in high speed, slow animated icons when pumps are in low speed.



Blower icon

The "Blower" indicator icon becomes animated when blower is on.



Service icon

A problem has been detected. Do not enter the water! Spa service is required.



Smart winter mode icon

The "SWM" icon automatically turns on when **Smart winter mode** is enabled. It blinks while performing a freeze protection purge.



Economy mode icon

The "Economy" icon flashes when Economy mode is on.




Filter Cycle icon

The "Filter Cycle" icon becomes animated when filter cycle is on. It flashes when filtering is suspended.



Waterfalls icon

The "Waterfalls" icon becomes animated when waterfall is on



Icon Description



Heater icon

The "Heater" icon becomes animated when the heater is on.



Progress bar

A visual indication of the time remaining before an equipment is turned off or before the end of the standby mode.



Set Point icon

The "Set Point" icon automatically turns on when set point setting menu is activated. (SP message on display). It flashes when:

- 1- there is a call for heat and heater has not started yet,
- 2- heater has just turned off and element is cooling down or
- 3 - if system is performing a check flow.



Standby icon

The Standby icon flashes when the standby mode is on.



Navigation icon

The navigation icon indicates the available active keys to navigate between options or screens within a given menu i.e.: **+**, **-**, **Ok**, **Right** or **Left** keys.



Lock icon

When the keypad is locked, the lock icon is displayed.




Hourglass icon

The Hourglass icon is displayed on the keypad screen when it asks you to wait.



Installation in.k600 low profile




To install the in.k600 low profile, use the drilling template provided in this section. Determine the mounting location and stick the template on chosen location. The user must cut out a rectangular shape opening of 7.250" by 3.750" according to the template (see illustration).

Clean the installation surface and peel the adhesive gasket from the back of the keypad.

Insert keypad and align it correctly, then ensure it's properly glued by gently pressing evenly on the entire surface.


Installation in.k600 high profile




To install the in.k600 high profile, use the drilling template provided in this section. Determine the mounting location and stick the template on chosen location. The user must cut out two 0.25" diameter holes for the fixation studs and one 2" diameter hole for the cable (as illustrated above).

Clean the installation surface and peel the adhesive gasket from the back of the keypad.

Insert keypad and align it correctly, then secure it properly in place by using the two wing nuts provided.








Connecting in.k600 keypad to in.xm

To connect the in.k600 keypad, simply insert its in.link connector into the appropriate keypad connector of the in.xm enclosure (as illustrated).


To provide additional access-control, an auxiliary keypad is also available (optional).





Main Modes

These menus allow access and control of the main devices controlled by the in.k600 keypad.



Spa Mode

This menu allows the control of the pumps and light as well as the activation of diverse programming modes. Various icons become animated to let you know present spa status.

Audio

This menu allows you to activate and control audio functions.


Future Release Features (To Be Determined)



Options Mode

This menu allows you to personalize operating settings of your spa equipment such as programming spa and keypad settings, setting the clock and finally, viewing software information.



Spa Mode Sub-Menus





Spa Mode

This menu allows control of all pumps, blower, waterfalls, spa light, as well as the activation of the Economy and Standby modes. As a convenient feature every time a device is on, its icon becomes animated to see its activation status. If you want to stop all motor activity at once you can do so by activating the Standby mode.


- Press **Mode** key  to display the mode selection window.
- Select **Spa** to view Spa menu.



Starting Pump 1 (1)

- Select **Pump 1** to turn Pump 1 on.
- Select **Pump 1** repeatedly to control Pump 1 speeds.


The pump icon becomes animated when Pump 1 is running. A built-in timer turns Pump 1 off after a certain period of time unless manually deactivated first.



Starting Pump 2 (2)

- Select **Pump 2** to turn Pump 2 on.
- Select **Pump 2** repeatedly to control Pump 2 speeds.


The pump icon becomes animated when Pump 2 is running. A built-in timer turns Pump 2 off after a certain period of time unless manually deactivated first.



Starting Pump 3 (3)

- Select **Pump 3** to turn Pump 3 on.
- Select **Pump 3** again to turn Pump 3 off.

The pump icon becomes animated when Pump 3 is running. A built-in timer turns Pump 3 off after a certain period of time unless manually deactivated first.




Starting Light (4)

- Select **Light** key to turn light on.
- Select **Light** key again to turn light off.

Light icon becomes animated when light is on.

A built-in timer automatically turns light off after a certain period of time unless manually deactivated first.



Next menu page

- Press **Next** key to display the next page in the spa menu.

This page allows you to select and control the following optional features: Pump 4, Pump 5, Waterfalls and Blower.




*Starting Pump 4

- Select **Pump 4** to turn Pump 4 on.
- Select **Pump 4** again to turn Pump 4 off.

Pump icon is animated when Pump 4 is on.

A built-in timer automatically turns pump 4 off after a certain period of time unless manually deactivated first.




*Starting Pump 5

- Select **Pump 5** to turn Pump 5 on.
- Select **Pump 5** again to turn Pump 5 off.

Pump icon is animated when Pump 5 is on.

A built-in timer automatically turns pump 5 off after a certain period of time unless manually deactivated first.



*Starting Blower

- Select **Blower** to turn blower on.
- Select **Blower** again to turn blower off.

Blower icon is animated when blower is on.

A built-in timer automatically turns blower off after a certain period of time unless manually deactivated first.

** Optional feature depending on spa configuration.*




*Starting waterfalls

- Select **Waterfalls** to turn waterfalls on.
- Select **Waterfalls** again to turn it off.

Waterfalls icon is animated when waterfalls is on.


A built-in timer automatically turns waterfalls off after a certain period of time unless manually deactivated first.



Next menu page

- Press **Next** key to display the next page in the spa menu.


This page allows you to select and control the following: Economy mode and the Standby mode.



Turning Economy on

The Economy mode allows you to lower the temperature set point of the spa by 20°F (11°C) during a certain period of the day. When in Economy mode, the "Economy Mode" icon flashes.

- Select **Economy** to activate the economy mode.
- Select **Economy** again to override economy programming (see spa setup section)



Standby Mode

When this feature is activated it allows you to stop all pumps at once by a simple click of a button! (light and audio features will remain active).

- Select **Standby** to activate this mode.
- Select **Standby** again to resume normal operations.

(see next page)

* Optional feature depending on spa configuration.




Displaying time

Please note that the system automatically returns to Normal mode after a certain period of time, unless the Standby mode has been reactivated.

In order to warn the user, the spa light will flash for a few seconds before exiting the Standby mode and the restart of all pumps by the system. The "Standby" message is also displayed during Standby mode.

** Pump will stay turned on if there is a request for more heat.*

- Press **Ok** key to display the time.
- Press **Ok** key a second time to go back to water temperature display.




Viewing active progress bars

A progress bar is a visual indicator of the time remaining before a device is turned off or before the end of the Standby mode. Only one bar is displayed at the time.

- Use **Left** or **Right** keys to visualize the progress bar of each activated device.



Options sub-menus



Spa settings

This menu allows you to personalize operating settings of your spa such as filtration, economy as well as reminder (active maintenance) and warning messages.

Keypad settings


This menu allows you to activate keypad functions.

Clock settings

This menu allows you to set the clock.

Info settings

This menu allows you to access spa equipment information on the spa controller, heater and keypad software updates.




Setting filter cycles

To program the filter cycle, you must enter these parameters: the start time, duration and frequency. During a filter cycle, pumps run for one minute to purge the plumbing, then Pump 1 runs for the programmed number of hours.

- Press **Mode** key
- Select **Options** menu
- Select **Spa** sub-menu
- Select **Filter** option


Setting filter cycle start time

The display will show the starting hour previously set.

- Use **+** or **-** key to set new hour setting.
- Use **Right** key to set minutes.
- Use **+** or **-** key to change minutes setting.
- Select **Next** arrow  on screen menu to go to the next parameter: filter cycle duration.


Setting filter cycle duration

Here we set a value for the filter cycle duration, in hours and minutes.

- Use **+** or **-** key to change hour setting.
- Use **Right** key to set minutes.
- Use **+** or **-** key to change minutes setting.
- Select **Next** arrow  on screen menu to go to the next parameter: filter cycle frequency.

Setting filter cycle frequency

Here we set the number of filtering cycles that the system will perform per day.

- Use **+** or **-** key to change the frequency setting.
- Select **Enter** option  on screen menu to save changes and go back to options main menu.




Setting Economy mode


To program the Economy mode, you must enter these parameters: the start time and stop time.


- Press **Mode** key.
- Select **Options** menu.
- Select **Spa** sub-menu.
- Select **Economy** mode.

Setting Economy start time

- Use **+** or **-** key to set hour setting.
- Use **Right** key to access minutes option.
- Use **+** or **-** key to set minutes.
- Select **Next** arrow  on screen menu to go to the next parameter: Stop time.

Setting Economy stop time

- Use **+** or **-** key to set hour setting.
- Use **Right** key to access minutes option.
- Use **+** or **-** key to set minutes.
- Select **Enter** option  on screen menu to save changes and go back to options main menu.



Setting maintenance reminder prompts


Periodically, the system will indicate that it's time for your spa check-up or to perform various maintenance tasks on your spa, i.e.: clean filter.


This menu allows you to activate/deactivate or simply reset the maintenance reminder prompts.

- Press **Mode** key
- Select **Options** menu
- Select **Reminder** option






Turning reminders on/off

- Use **+** or **-** key to activate or deactivate prompt(s).
- Select **Next** arrow  on screen menu to go to the next menu screen.



Resetting prompt messages

- Select **Enter** option  on screen menu to reset message and go back to the main menu. Thus indicating that a maintenance task is done.
- Select the  option to close the window and go back to the main menu, should you want to postpone the indicated task. The reminder message will return at a later time.



Viewing spa reminders

The reminder icon will show up to prompt you to review active maintenance messages.



Spa warnings

This menu allows you to view all active warning messages ie.: hot water.


- Press **Mode** key
- Select **Options** menu
- Select **Warning** option
- Press **Mode** key again to go back to the main menu.

Viewing spa warnings

The warning icon shows up to prompt you to review active warning messages.

Postponing spa warnings

- Select the **X** option to close the window and go back to the main menu. The warning message will return at a later time.



Setting keypad display options

This sub-menu is used to set keypad display settings such as: contrast, backlight, normal or reverse display and finally inverted display.


- Press **Mode** key
- Select **Options** menu
- Select **Keypad** sub-menu
- Select **Display** options



Adjusting contrast

Contrast should be set for comfortable viewing.


- Use **Left** or **Right** keys to adjust desired level of contrast.
- Select **Next arrow** ➡ on display to go to next screen menu.



Adjusting backlight

Adjust to gain more control over screen brightness when use in low-light conditions.


- Use **Left** or **Right** keys to adjust backlight brightness.
- Select **Next arrow** ➡ on display to go to next screen menu.



Normal/Reverse display

Also known as negative display, this option enables you to reverse the appearance of text to white letters on a black background. Thus, reducing glare for many users.

- Use **+** or **-** key to activate or deactivate reverse display.
- Select **Next arrow** ➡ on display to go to next screen menu.




Display orientation

This feature inverts the display* to make it readable from inside or outside the spa. To invert display:

- Use **+** or **-** key to activate or deactivate reverse display.
- Select **Enter** option ☒ on screen menu to save changes and go back to the main menu.

** When this feature is enabled, the functionality of all keys is inverted as well.*



Setting keypad audio options


This sub-menu is used to set keypad audible options setting such as: keypad on/off (key beep), and alarm on/off.


- Press **Mode** key
- Select **Options** menu
- Select **Keypad** sub-menu
- Select **Sound** options



Keypad on/off


To enable/disable key beep:


- Use **+** or **-** key to activate or deactivate key beep.
- Select **Next** arrow  on display to go to next screen menu.



Turning alarm sound on

This feature alerts you when an error condition has occurred.

- Use **+** or **-** key to activate or deactivate alarm sound.
- Select **Enter** option  on screen menu to save changes and go back to the main menu.




Setting regional settings

This sub-menu is used to set keypad regional settings such as: language (you can choose from English, Francais, Español or Deutsch), select temperature display units and choose a format for time display.

- Press **Mode** key
- Select **Options** menu
- Select **Keypad** sub-menu
- Select **Regional** options




Setting language


- Use **+** or **-** key to select from: English, Francais, Español or Deutsch.
- Select **Next arrow**  on display to go to the next screen menu.



Temperature units


Water temperature can be displayed in °F or °C.


- Use **+** or **-** key to change setting.
- Select **Next arrow**  on display to go to the next screen menu.



Selecting time format

This feature allows you to switch display from regular to military time format.


- Use **+** or **-** key to change setting.
- Select **Enter** option  on screen menu to save changes and go back to keypad main menu.



Security options

This sub-menu allows you to lockout your keypad to prevent unauthorized parameter setting of the unit. You may choose between partial lock or full keypad lock.


Partial keypad lock: the basic functions of the spa remain accessible (pump and light outputs) but it's impossible to change the temperature Set Point, or to enter the Programming mode.

Full lock: all keys are disabled. When the keypad is locked, the  icon will be displayed.


- Press **Mode** key
- Select **Options** menu
- Select **Keypad** sub-menu
- Select **Security** options




Partial keypad lockout

- Use **+** or **-** key to select ► "Partial".
- Select **Enter**  option on screen menu to go back to spa main menu.


To unlock the keypad, select and hold **Options** menu soft key for 5 seconds.



Full keypad lockout


- Use **+** or **-** key to select ► "Full".
- Select **Enter**  option on screen menu to back to spa main menu.

To unlock the keypad, press and hold **Light** key for 5 seconds.



Setting the time

- Press **Mode** key
- Select **Options** menu
- Select **Keypad** sub-menu
- Select **Clock** setting
- Use **+** or **-** key to set hour setting.
- Use **Right** key to access minutes option.
- Use **+** or **-** key to set minutes.
- Select **Enter** option ☒ on screen menu to save changes and go back to keypad main menu.



Viewing information about the system

This sub-menu allows you to view spa equipment data such as: spa controller, heater and keypad software version. Also, here it's possible to reset programmed settings back to default factory values and finally to upgrade keypad software.

- Press **Mode** key
- Select **Options** menu
- Select **Info** sub-menu



Viewing information about the spa controller

Here the spa controller software ID number and version are displayed.


- Select **Next** arrow  on display to go to the next screen menu.



Viewing information on heater software

Here the heater software ID number and version are displayed.


- Select **Next** arrow  on display to go to the next screen menu.



Viewing information on keypad software

Here the keypad software ID number and version are displayed.

- Select **Next** arrow  on display to go to the next screen menu.



Resetting keypad programmed values


Here is possible to reset programmed settings back to original factory values.

- Press **Ok** to reset back to default factory values.


Or simply:

- Select **Next** arrow  on display to go to the next screen menu.

Upgrading keypad software


- Use **Ok** key to start software upgrade of the keypad.
- Select the  option to abort upgrading operation.

Should you desire **Not** to upgrade the keypad software simply:

- Select **Enter** option  on screen menu to back to Options main menu.




Audio Mode Sub-menus





Audio Mode

- Press **Mode** key.
- Select **Audio** mode.



Power On/Off

- Select **Power** to turn system on or off.

When power is off, time is displayed.




Source **SRC**

In audio mode:

- Select repeatedly **SRC** to choose between the following (in order):


Tuner, cd (in.tune) / dvd (in.pix) or Aux.



Selecting radio band **Band**

In tuner mode:


- Press **Mode** key.
- Select **Audio** mode.
- Press **Next** key.
- Select **Band** to select between FM1, FM2, FM3, AM1, AM2 and WB (weather band).



Tuning up or down ◀ ▶

In tuner mode:

- Press **Mode** key.
- Select **Audio** mode.
- Select repeatedly **SRC** to select Tuner option.
- Press ▶ key to make a seek up to the next preset station.
- Press ◀ key to make a seek down to the next preset station.



Auto scan mode A/PS

In tuner mode:

- Press **Mode** key.
- Select **Audio** mode.
- Press **Next** key repeatedly to select **A/PS** to scan preset stations. The tuner will scan up and wait for a few seconds, then scan up again.


Once the desired station is found, select **A/PS** again to stop Scan mode.



Selecting weather band mode ☀

In tuner mode:

- Press **Mode** key.
- Select **Audio** mode.
- Press **Next** key repeatedly to select **Weather** to access Weather band mode (or press **BAND** in Tuner mode until WB is displayed).
- It automatically skips to the strongest weather channel.
- Select **Weather** again to turn off weather band radio and return to previous mode.



Selecting weather station ☀

In tuner mode:

- Press **Mode** key.
- Select **Audio** mode.
- Press **Next** key repeatedly to select **Weather** to access Weather band mode (or press **BAND** in Tuner mode until WB is displayed).
- Press ▶ to go to the next memorized weather channel (CH1 to CH7).
- Press ◀ to go to the previous memorized weather channel (CH1 to CH7).



Display information

cd containing mp3 files:

- Press **Mode** key.
- Select **Audio** mode.
- Select **SRC** to select CD option.
- Press **Next** key repeatedly to display the next page in the audio menu.
- Successively select **Display** to switch between the following display information:

Track no. / Playtime - Clock
(clock is displayed for 5 seconds only).

If you inserted a CD containing MP3 files, a different display info will appear if you select **Display**:

Track no. / Playtime - Folder no.
/ Track no. - Folder name - File name - Song name - Artist's name - Album name - Clock
(clock is displayed for 5 seconds only).

The system can only display the first 8 letters of ID3 tags. If the recorded information is longer than 8 letters, text will scroll to the left once, then the 8 first letters will be displayed.

If specific info has not been recorded on an MP3 disc, NO FOLD, NO TRK, NO TLT, NO ALBM, NO ART will be displayed.




Intro scan

In cd mode:

You can preview each song of the current disc for about 10 seconds.

- Press **Mode** key.
- Select **Audio** mode.
- Select **SRC** to select CD option.
- Press **Next** key repeatedly to display the next page in the audio menu.
- Select **Scan** mode.
- Select **Scan** mode again to turn off this feature.




Repeat

In cd mode:

To play a song repeatedly:

- Press **Mode** key.
- Select **Audio** mode.
- Select **SRC** to select CD option.
- Press **Next** key repeatedly to display the next page in the audio menu.
- Select **Repeat**.
- Select **Repeat** again to turn off this feature.



Random

In cd mode:

- Press **Mode** key.
- Select **Audio** mode.
- Select **SRC** to select **CD** option.
- Press **Next** key repeatedly to display the next page in the audio menu.
- Select **Random** to play song tracks randomly.
- Select **Random** again to turn off this feature.



Track up or down

In cd mode:


- Press **Mode** key.
- Select **Audio** mode.
- Select **SRC** to select **CD** option.
- Press **Next** key repeatedly to display the next page in the audio menu.
- Press **◀** or **▶** to change music tracks.



Pause

In cd mode:

- Press **Mode** key.
- Select **Audio** mode.
- Select **SRC** to select **CD** option.
- Press **Next** key repeatedly to display the next page in the audio menu.
- Select **Pause** to pause the playing of a disc.
- Select **Pause** again to resume play.




Changing discs

In cd mode:

- Press **Mode** key.
- Select **Audio** mode.
- Select **SRC** to select **CD** option.
- Press **Next** key repeatedly to display the next page in the audio menu.
- Select **◀○** or **○▶** to switch *CDs.
- Press **Next** key to go back to the main page in the audio menu.

* option only available on equipment with cd changer.



Tone **Tone**

In all modes:

- Select **Tone** to select either (in order): volume, bass, treble, balance or fader.
- Use **+** or **-** key to change the desired parameter.


Bass control: Adjusts the amount of low frequency that you hear.

Treble control : Adjusts the amount of high frequency that you hear.

Balance control: Adjusts the amount of sound output to the left and right speakers.

Fader control: Adjusts the amount of sound output (see **Fader** on next page).

Note: Bass and Treble settings are available only if EQ is set to DSP Off.



Fader


In all modes:

- Select **Fader** option repeatedly to select from one of the following adjustments:

FAD-FRONT: Front speaker only.

FAD-REAR: Rear speaker only.

FAD-ALL: Front and rear speakers.



Equalization

In all modes:

- Successively selecting **EQ** will allow you to choose from: DSP Off, Jazz, Pop, Classic, Rock or Vocal.



Volume Up or Down

In all modes:

- Use **+** or **-** key to increase or decrease volume.



Muting the audio output

In all modes:


- Select Mute to render silent the audio output.
- Select Mute key again to return to previous volume level.



Selecting in.pix

This feature allows to select an external audio/video source such as the in.pix.

- Press **Mode** key
- Select **Options** menu
- Press **Next** key
- Select **Audio** option
- Use **+** or **-** key to choose from the in.tune, in.pix or none.
- Select **Enter** option ☒ on screen menu to save changes and go back to keypad main menu.




Navigation keys ◀ ▶

In DVD mode:

- Press **◀** or **▶** to navigate horizontally through the various DVD menu on monitor screen.

While viewing a DVD:

- Press **◀** or **▶** to navigate through the various DVD chapters on monitor screen.




Navigation keys + -

In DVD mode:

- Use **+** or **-** key to navigate vertically through the various DVD menus on monitor screen.

While viewing a DVD:


- Press **+** or **-** to increase or decrease DVD volume.



Menu

In DVD mode:

- Select **Menu** option to display DVD menu on monitor screen.




Stop DVD

In DVD mode:

- Use **Ok** key to select an option from the various DVD menus on monitor screen.

While viewing a DVD:


- Press **Ok** key to stop DVD.



Zoom

In DVD mode:

- Select **Zoom** option to enlarge or reduce image on monitor screen.



DVD language

In DVD mode:

- Select **Language** option to choose language from DVD menu on monitor screen.



General specifications:

Environmentals

Storage temperature: 85°C (185°F) to -30°C (-22°F)

Operating temperature: 65°C (149°F) to -20°C (-68°F)

Humidity: up to 100% condensing

Standards:

IP ratings IPX6

Mechanical Specs

Weight: 0.48 Kg (1.05 lbs)

Dimensions (W x H x D): Front panel

High Profile: 7.250" x 3.75" x 0.655"

Low Profile: 8.684" x 4.234" x 0.200"

Specifications and design are subject to change without prior notice.

Advanced electronics! Water resistance!



Aeware 3
by gecko

Gecko Alliance

450 des Canetons, Quebec City (QC) G2E 5W6 Canada, 1.800.78.GECKO
9225 Stellar Court, Corona, CA 92883 USA, 1.866.639.7274

www.geckoalliance.com